

SmartHook can be mounted directly over drywall – no need for a separate board!

1 Mark Position



2 Drill 3/32" Pilot Holes



3 Drive Screws



Installation into Wall Stud