## **Easy Open Gate Latch Assembly**

customers will have an issue during installation

The Easy Open Gate Latch will assembled in the package but occasionally


**Mounting Bracket** 





Spring/Guide

1. Attach spring/slide to mounting bracket Plastic tabs on back of spring/guide go into two rectangular holes on bracket



2. Position handle and bracket assembly as shown. Insert handle into plastic guide - see next step



Make sure edge of metal tab is to the left of the spring

3. Handle fits between top and bottom plastic guides



**Cover Plate** 

4. Attach cover plate to assembly. Four rectangular holes snap on to tabs on plastic guide/spring

Mounting bracket/ Spring Assembly